

# Oregon Phone Quick Reference Guide For Partner R1 – System Programming

**System Programming** – From extension 10 dial **Feature 00**, then press the **Left Intercom** button 2 times to enter **System Programming**. The numbers in parentheses after the program item heading are the factory default values. To end the **System Programming** session dial **Feature 00**. Displays don't work on this version.

## **Recall Timer (18=450msec)**

Dial #107  
Dial recall interval (01-80)  
Each increment of 1 = 25msec

## **Hold Disconnect Time (1)**

Dial #203  
1=Long-450msec, 2=Short-50msec

## **Outgoing Call Restriction (1)**

Dial #401  
Dial extension (10-21)  
1=No restriction, 2=Restricted

## **Dial Mode (1)**

Dial #201  
1=Touchtone, 2=Rotary

## **Abbreviated Ringing (1)**

Dial #305  
Dial extension (10-21)  
1=On/1 ring, 2=Off/repeated ringing

## **System Initialization**

Dial #989  
Dial 25327 (CLEAR)  
System returned to factory default

# Oregon Phone Quick Reference Guide For Partner R1 – Centralized Programming

**Centralized Programming** – From extension 10 (MLS-6 or MLS-12) dial **Feature 00**, press the **Left Intercom** button 2 times, then press the **Right Intercom** button 1 time to enter **Centralized Programming**. The following station features can **only** be changed in **Centralized Programming**. To program another extension, press the **Right Intercom** button. Dial **Feature 00** to end the programming session.

**Automatic Line Selection** (Do this procedure first before programming other features)

Dial extension (10-21)

Dial \*\*

Touch line buttons in the order of desired selection. (To select intercom dial tone, touch the **Left Intercom** button first, then touch line buttons in the order of desired selection.)

Dial \*\* to end

## **Line Ringing**

Dial extension (10-21)

Observe the green lights for each line assigned to the extension.

**Immediate Ring** = Steady light

**No Ring** = Fast fluttering light

Press each line button until the desired ring option is set.

# Oregon Phone Quick Reference Guide For Partner R1 – Auto/Speed Dialing

## Auto Dial – Outside (MLS-12 only)

Enter **Station Programming**, or **Centralized Programming**

Press the button to be programmed

Dial outside phone number (Up to 20 digits including special dialing characters)

## System Speed Dial (Note: NOT Done In System Programming)

At extension 10, dial **Feature 00**

Press **Feature** followed by a 2-digit speed dial code (20-79)

Dial phone number (Up to 20 digits including special dialing characters)

Dial **Feature 00** to end

## Special Dialing Characters

Pause = Press **Hold**

Recall (Flash) = Press **Spkr**

Stop = Press **Mic**

Touchtone Enable = Press **Transfer**

**Brian Cox**  
**Oregon Phone**  
**541-267-5369**